

Japon Miyota JP25



MOMENTUS


BUILT FOR PERFECT MOMENTS

Kullanım Kılavuzu

User Guide

KULLANIM KILAVUZU - Japon Miyota JP25

A) EKRAN GÖRÜNTÜSÜ



B) SAATİN VE GÜNÜN AYARLANMASI

- 1) Kurma Kolu'nu 2 kere çekin. Saniye Kolu duracaktır.
- 2) Kurma Kolu'nu, Akrep ve Yelkovan istenen saat ve dakikaya gelene kadar çevirin.
- 3) Günü ayarlamak için tepeyi çevirerek 24 saati tamamlayın. Her 24 saatlik dönüşte aşağıda kısaltmaları yazan günler değişecektir.
MON: Pazartesi
TUE: Salı
WED: Çarşamba
THU: Perşembe
FRI: Cuma
SAT: Cumartesi
SUN: Pazar
- 4) Saati ve günü ayarladıktan sonra Kurma Kolu'nu iterek Normal Pozisyon'a getirin. Saniye Kolu çalışmaya başlayacaktır.

C) TARİHİN AYARLANMASI

1) Kurma Kolu'nu 1 kere çekin.

2) Tepeyi çevirerek istenilen tarih görünene kadar çevirin.

* Tarih ayarını saat 21:00 ile 01:00 arası yaparsanız, ertesi gün tarih doğru değişmemektedir.

3) Tarihi ayarladıktan sonra Kurma Kolu'nu iterek Normal Pozisyon'a getirin.

D) İKİNCİ ZAMAN FONKSİYONU

* Saatiniz çift zaman gösterebilen bir mekanizmaya sahiptir.


1) A düğmesine her basışınızda İkincil Saat Kolu 15 dakika ileri gidecektir.

2) B düğmesine her basışınızda İkincil Saat Kolu 15 dakika geri gidecektir.

* A veya B düğmelerine devamlı basılı tutduğunuzda İkincil Saat Kolu hızlı hareket edecektir.

USER GUIDE - Japan Miyota JP25

A) DISPLAYS AND BUTTONS



B) SETTING THE DAY

- 1) Pull the crown out to the 2nd Click Position.
 - 2) Turn the crown clockwise to set the day.
 - 3) After the day has been set, push the crown back to the Normal position.
- * The day is changed during the period from 0AM to 5AM.

C) SETTING THE DATE

- 1) Pull the crown out to the 1st Click Position.
 - 2) Turn the crown clockwise to set the date.
- * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
- 3) After the date has been set, push the crown back to the Normal position.

D) SETTING THE TIME

- 1) Pull the crown out to the 2nd Click Position.
- 2) Turn the crown clockwise to set hour and minute hands.
- 3) After the time has been set, push the crown back to the Normal position.

E) SETTING THE DUAL TIME

Press button "A" to set the dual time hand forward in units of 15 minutes.

Press button "B" to set the dual time hand back in units of 15 minutes.

*The dual time hand can be set rapidly by continuously pressing button "A" or "B".